

# Controller

## Controller: First Time Use

For first time use, make sure to practice in an open area. Practice maneuvering left and right and slowing down, speeding up and stopping. The remote controller is rated for a range of 50 yards, but you can often control it up to a range of 100 yards or more. However, we do not recommend running your cart unattended in case there are obstacles, or interference with transmission. The Club Booster has two-way communication, so it will stop automatically when the remote is out of range.

## Controller: Speed Control

Speed control is as important on the course as it is on the road. Your Club Booster has six speeds. The default speed is Level 3. You can speed up by pushing the "GO/Speed Up" button, or slow down by pushing the "BACK/Speed Down" button.

---

### IMPORTANT

When you stop your cart, the next time you push GO your Club Booster will start at the last speed used. This is VERY important, because the cart is often stopped around greens and tee boxes that require maneuverability and care around other players, their equipment and the surrounding area.

We therefore HIGHLY recommend slowing the Club Booster down to its slowest speed when approaching the area where you wish to stop. This will make the cart easier to maneuver both before and after it is stopped. As stated earlier, fixed-wheel carts may not be able to turn at higher speeds and may endanger others or damage property if the unit starts at a high rate of speed and cannot be turned.

---

Press the "Go/Speed Up" button and the cart will move forward.

Press the "Stop" button and the cart will stop. For a smoother stop, slow the cart down prior to stopping. To reverse the cart, hold down the "Back/Speed Down" button and release the button to stop.

